Product features CHELIC.

### Feature

- Function integration: vacuum, breaking, digital display, filter and silencer
- Quick wiring: cable connector, easy to install.
- Expandable: Max. 8 manifolds
- Energy-saving:Intelligent compensation, reducing power supply.



### ■ Single unit Specification

Item	Model		VSL-A	
Fluid			Air	
Pressure range	MPa (kPa)		0.2 ~ 0.6 ( 200 ~ 600 )	
Proof pressure	MPa (kPa)		0.5(500)	
Vacuum value	kPa (mmHg)		-90(675)	
Nozzle diameter	mm	0.5	0.7	1.0
Max. suction flow	L/min	6	9	15
Ambient and fluid temperature °C		0~40		
Material	Body		Copper (Nickel plating)	
Material	Plastic		NYLON, PBT	
Port size	Port size mm Ø6			
V port	mm	m Ø4		
Exhaust type			Atmospheric emissions	
Valve type			SR2 - 100	
Rated voltage	V		24±10%VDC	
Power consumption w			1.2	

### ■ Manifold type Specification

Item	\ Model	VSL-B
Product function/ Material/ Voltage		Unified specifications
Common supply port size mm		Ø8
Individual exhaust port size mm		Ø4
Unified exhaust type		Atmospheric emissions, Ø 8 tube
Manifold type		1 ~ 8 M

### Pressure switch specification

Item	Model	With Pressure switch embeded
Pressure range setting	ng kPa	- 101.0~0
Pressure range	kPa	-100.0~100.0
Withstanding pressu	ire kPa	500
Applicable fluid		Filtered air, Non-corrosive, Non-flammable gas
Power voltage		12 to 24V DC $\pm$ 10%, Ripple $\leq$ 10%
Response time	ms	≤ 2.5(Chattering-proof function: 25, 100, 250, 500, 1000 and 1500 selectable)
Repeatability		$\pm$ 0.2% F.S. $\pm$ 1 digit
Current consumptio	n mA	≤ 40( With no load )
	Enclosure	IP40
	Ambient Temp. Range ° C	0 ~ 50 (No condensation or freezing )
	Ambient Humidity Range RH	Operation/ Storage: 35 ~ 85 % RH ( No c ondensation )
Environmental Resistance	Withstand Voltage	1000 V AC in 1-min ( between case and lead wire )
resistance	Insulation	$\geq$ 50 M $\Omega$ ( at 500 V DC, between case and lead wire )
	Vibration	Total amplitude 1.5 mm , 10 Hz ~ 55 Hz sc an for 1 minute, two hours each direction of X, Y and Z
	Impact	980 m/s $^2$ ( 100G ) , 3 times each in direction of X, Y and Z
Temperature Characteristic		±2% F.S. (within 0–50° C temperature range)

Code of order

CHELIC.

Code of order -Integrated type vacuum ejector/ Single unit

VSL - A 10 - DC24 - P04 - S - C1 1 2 3 4 5 6


1	Mark	Model
	Α	Single unit

2	Mark Nozzle (mm)	
	05	Ø0.5
	07	Ø0.7
	10	Ø1.0

3	Mark	Voltage
	DC 12	12V, 1.2W
	DC 24	24V, 1.2W

4	Mark	Output
	P04	NPN output + Analog
	P05	PNP output + Analog
	P06	Analog1~5V

5	Mark	Cable connector
	S	Straight type 2m
	Н	Angle type 2m



C1: Included rail 107.1mm


8

Code of order - Integrated type vacuum ejector/ Manifold type


VSL - B 10 - 02 - E1 - DC24 - P04 - S - C3



2	Mark	Nozzle (mm)
	05	Ø0.5
	07	Ø0.7
	10	Ø1.0



Mark	Exhaust	l
E1	Atmospheric emissions	
E2	Ø 8 tube	
Image		



E1: Atmospheric emissions
E2: Ø 8 tube

Mark	Voltage
DC 12	12V, 1.2W
DC 24	24V, 1.2W

Mark	Output			
P04	NPN output + Analog			
P05	PNP output + Analog			
P06	Analog1~5V			

Mark	Cable connector
S	Straight type 2m
Н	Angle type 2m

Mark	Bracket					
None	Without Rail					
C3	Rail bracket					
Image						

Without Rail
C3: Rail bracket

Without Rail: 4 x M4x20L screw

C3: Manifold rail length (Chart 1)

Mark	Rail length (L)				
1~2 M	107.1				
3~4 M	142.8				
5~6 M	178.5				
7~8 M	214.2				

EV

EVM

VA 🗆

VM 🗆

VM □ U

VHS

VSL

VKM

VKMT

VCK

VK20□

VK30□

VQ20□

VFD

VFM

VFU


ERV

**ERVL** 

MVS

Product features CHELIC.

#### Internal structure



### Components and Material list


No.	Item	Material	No. Item		Material	
1	Base body	Relieving type	6	Nozzle	Copper	
2	Backstop shaft	Copper	7	Vacuum copper tube	Copper	
3	Down axis	Copper + NBR	8	V port filter	Foam cotton	
4	Plastic suction connector	Relieving type	9	Supply filter	Foam cotton	
5	Cover	Relieving type	10	Body upper seat	Relieving type	


### Product weight


Item	Model	Weight(g)							
Integrated type vacuum ejector -Single unit	VSL-A	65							
Integrated type vacuum ejector	VSL-B-0108	1 M	2 M	3 M	4 M	5 M	6 M	7 M	8 M
- Manifold type	V3L-D-0100	155	220	285	350	415	480	545	610

### ■ Flow Rate Characteristics

The flow characteristic is that when the generator sucks in the air to reach the vacuum, the relationship between the inhaled air flow and the consumed air volume.







Component Replacement

CHELIC.

### Single Unit Components


#### A. Fitting replacement

#### P port/ EXH port:

- (1) Dismentling fitting clips.
- (2) Take out the fittings, then put into new fittings.
- (3) Place new fittings onto ejectors and put back the fitting clips.

#### B. Filter element replacement

- Vacuum port:
- (1) Pull out the vacuum port fitting.
- (2) Take out the element and replace.
- (3) Position the element into the ejector, then rotate vacuum fitting back to the port.



### Component Replacement

A. How to increase manifold stations

(1) Remove three tension bolts.

(2) Dismentling right end plate. (Beware the packing to avoid air leakage caused by the wrong position.)

(3) Mount a single unit to the end surface. (Beware the packing to avoid air leakage caused by the wrong position.)


(4) Lock three tension bolts.


#### B. Silencer cover replacement

Sound absorbing element:

(1) Remove the clip.

(2) Remove the silencer cover, pull out the sound absorbing element.





EV

EVM

VA 🗆

VM 🗆

VM□U

VHS

VSL

VKM

VKMT

VCK

VK20□

VK30□

VQ20□

VFD


VFM

VFU

ERV

**ERVL** 


MVS




Wiring/ Caution expression

CHELIC

### Vacuum ejector/ Single unit



### Manifold vacuum ejector with individual wiring



### Caution For design, selection and maintenance



### WARNING

- Avoid chemical, corrosive and inflammable gas; avoid sea water, steam high temperature place in surrounding.
- Avoid oil contain gas, don't oil mist in the pipeline, oil in pipeline will cause blockage resuliting in poor effect.
- Please don't use fluid other than compressed air, never suck in fluid other than clean air.
- When using gas, the gas should be kept dry, and there should be no large amount of water vapor, which will cause the possibility of abnormal pressure detector.




### CAUTION


- Please don't disassemble the vacuum generator in discretion, error disassembing will lead to hazard and cause problem on operation of the product.
- Please be sure to use the supply pressure within the product specification range. If the maximum operating pressure is exceeded, the product may be damaged.
- During operation, please do not drop, hit, or apply excessive impact (100m/s) even if the body is not damaged, the internal part may be damaged and may cause malfunction.

Circuit Expression CHELIC.

### ■ Vacuum ejector/ Single unit



## ■ Vacuum ejector/ Manifold type



3-1.44

EV

EVM

VA 🗆

VM 🗆

 $\mathbf{VM} \square \mathbf{U}$ 

VHS

VSL

VKM

VKMT

VCK

VK20□

VK30□

VQ20□

VFD

VFM

VFU

---


ERV

ERVL

MVS

Installation CHELIC.


### Manifold Components description





# VSLNumeric Display Pressure Switch Setting Instructions (Numeric type)

- 1 sets of output & linear analogy output (1~5V)
- Compact size: 13mm(W)
- Key lock function
- Various pressure units available kPa, MPa, kgf/cm², bar, psi, inHg, mmHg

### O Various pressure units available









Key lock mode can prevent improper operation to pressure switch.


Key lock mode can pbe activated by pressing + and - for 3 seconds.


Dimensions CHELIC.

## ■ Vacuum Ejector/ Single Unit









EV

EVM

VA □

VM 🗆

 $\mathbf{VM} \square \mathbf{U}$ 

VHS

VSL

VKM

VKMT

VCK

VK20□

VK30□

VQ20□

VFD

VFM

VFU


ERV


ERVL


MVS

Dimensions CHELIC.

Compact Electronic/
Manifold type/Individual Wiring








							Un	it: mm
Manifold no. Mark	1	2	3	4	5	6	7	8
L1	45	69.3	82.3	95.3	108.3	121.3	134.3	147.3
L2	58	83	96	109	122	135	148	161
							(C	hart 1)

Unit: mm							
Manifold no.	Rail length (L)						
1~2 M	107.1						
3~4 M	142.8						
5~6 M	178.5						
7~8 M	214.2						
(Chart 2)							



**MEMO** 

CHELIC.

EVM

EV

**VA**  $\square$ 

VM 🗆

 $\mathbf{VM} \square \mathbf{U}$ 

VHS

VSL

VKM

VKMT

VCK

VK20□

VK30□

VQ20□

VFD

VFM

VFU

ERV

ERVL

MVS

